


# Native BACnet MS/TP for CUE

Functional profile and user manual





# Native BACnet MS/TP for CUE

---

## English (GB)

|  |   |
|--|---|
| Functional profile and user manual ..... | 4 |
|--|---|

## Original functional profile and user manual

## Table of contents

|   |           |
|---|-----------|
| <b>1. General information</b>           | <b>4</b>  |
| 1.1 Hazard statements                   | 4         |
| 1.2 Notes                               | 4         |
| <b>2. Introduction</b>                  | <b>4</b>  |
| 2.1 Technical overview                  | 4         |
| 2.2 Assumptions                         | 5         |
| 2.3 Background knowledge                | 5         |
| 2.4 Abbreviations                       | 5         |
| <b>3. The BACnet Interface</b>          | <b>5</b>  |
| 3.1 Cabling                             | 5         |
| 3.2 Network connection                  | 5         |
| 3.3 Network termination                 | 5         |
| 3.4 Switches S201, S202, and S801       | 5         |
| 3.5 Cable routing                       | 6         |
| <b>4. Bus cabling</b>                   | <b>6</b>  |
| 4.1 EMC precautions                     | 6         |
| 4.2 Single ground shielding             | 6         |
| 4.3 Multiple ground shielding           | 6         |
| <b>5. System configuration</b>          | <b>6</b>  |
| 5.1 Configuring BACnet                  | 6         |
| 5.2 Control word time-out function      | 7         |
| 5.3 Example of a simple setup of BACnet | 7         |
| <b>6. BACnet objects</b>                | <b>8</b>  |
| 6.1 Analog input and output objects     | 8         |
| 6.2 Binary input and output objects     | 10        |
| 6.3 Multistate value objects            | 12        |
| 6.4 Real time clock variable            | 12        |
| 6.5 Feedback to network                 | 12        |
| 6.6 BIBBs                               | 12        |
| 6.7 Object/property support matrix      | 12        |
| <b>7. Parameters</b>                    | <b>14</b> |
| 7.1 Parameter list                      | 14        |
| 7.2 Parameter description               | 15        |
| <b>8. Troubleshooting</b>               | <b>19</b> |
| 8.1 Alarm, warning and extended status  | 19        |
| 8.2 Alarm words                         | 19        |
| 8.3 Warning words                       | 19        |

## 1. General information



Read this document before you install the product. Installation and operation must comply with local regulations and accepted codes of good practice.

## 1.1 Hazard statements

The symbols and hazard statements below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.

**DANGER**

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

**WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

**CAUTION**

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The hazard statements are structured in the following way:

**SIGNAL WORD****Description of the hazard**

Consequence of ignoring the warning

- Action to avoid the hazard.

## 1.2 Notes

The symbols and notes below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



Observe these instructions for explosion-proof products.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

## 2. Introduction

## 2.1 Technical overview

BACnet (Building Automation and Control Network) is an open data communications protocol, American National Standard (ANSI/ASHRAE 135-1995). BACnet provides a means by which computer-based control equipment from different manufacturers can work together. BACnet is designed to handle many types of building controls, including HVAC, lighting, security, fire, access control, maintenance and waste management. BACnet permits flexibility for expansion and different equipment combinations.

Conformance Classes, Function Groups and the PICS: Evaluating the capabilities of a BACnet device is potentially a formidable task, given the great choice of Objects, Properties and Services, which can be implemented, as well as the fact that it is not necessary for every BACnet device to have a full BACnet implementation in order to carry out its task. ASHRAE's BACnet Committee recognized this problem and responded with aids to evaluation in the form of Conformance Classes, Function Groups and the Protocol Implementation Conformance Statement (PICS).

The BACnet protocol defines six levels of Conformance Classes, each of which specifies the minimum subset of Services implemented on the device. The lowest level, Conformance Class 1, requires only that the BACnet device contain a Device Object and that it can execute (respond to) a ReadProperty Service request. Each successive Conformance Class level adds Service Requests that must be executable by the device, as well as the Service Requests it must be able to initiate. Conformance Class 6 requires 21 types of Service Requests (of the 32 overall) to be implemented, of which 20 must be initiatable and 17 executable. Conformance Class thus provides a measure of the device's ability to communicate.

Function Groups specify a combination of Objects and Services necessary to carry out certain building automation functions. They are specified independently of Conformance Class, though the implementation of some of the Function Groups automatically confers some Conformance Class higher than 1.

**Background information**

|                      |        |
|----------------------|--------|
| Protocol name        | BACnet |
| Technology developer | ASHRAE |
| Year introduced      | 1995   |

| Background information     |  |
|----------------------------|--|
| Governing standards        | ANSI/ASHRAE Standard 135-2008 version 4, ISO 16484-5 |
| Openness                   | Open specification                                   |
| Physical characteristics   |  |
| Network topology           | Bus  |
| Physical media             | Shielded twisted pair                                |
| Max. distance at low speed | 1200 m   |
| Transport mechanism        |  |
| Communication methods      | Master/slave   |
| Baud Rates Supported       | 9600, 19200, 38400, 76800                            |
| Termination                | 120 ohm  |

## 2.2 Assumptions

This manual assumes you are using the BACnet Protocol with a CUE series frequency converter. It is also assumed that your system is equipped with a firmware supporting the BACnet communication services required by your application and that all requirements stipulated in the BACnet standard are strictly observed as well as all limitations therein fully respected.

## 2.3 Background knowledge

The BACnet Protocol is designed to communicate with any system complying with the BACnet MS/TP standard. Familiarity with the PC, BMS or PLC used as a master in the system is assumed. Issues regarding hardware or software produced by other manufacturers are beyond the scope of this manual and are not the responsibility of Grundfos.

## 2.4 Abbreviations

|        |   |
|--------|---|
| ACI    | Acylical Control Interval   |
| AOC    | Application Orientated Controller   |
| AV     | Analog Variable   |
| BMS    | Building Management System  |
| BV     | Binary Variable   |
| CTW    | Control Word  |
| EEPROM | Electrical Erasable Programmable Read Only Memory                         |
| EIA    | Electronic Industries Association: Specifies of the EIA Standard RS 485-A |
| EMC    | Electromagnetic Compatibility   |
| I/O    | Input/Output  |
| ISO    | International Standards Organization                                      |
| LCP    | Local Control Panel   |
| LED    | Light Emitting Diode  |
| MAV    | Main Actual Value   |
| MRV    | Main Reference Value  |
| PC     | Personal Computer   |
| PDU    | Protocol Data Unit  |
| PELV   | Protected Extra Low Voltage   |
| PLC    | Programmable Logic Control  |
| PNU    | Parameter Number  |
| STW    | Status Word   |

## 3. The BACnet Interface

### 3.1 Cabling

#### Cable lengths and number of nodes


For the correct function of a BACnet MS/TP system, it is mandatory to fulfill installation of the communication cables given in this manual. Under correct installation it is possible to have up to 250 nodes (125 masters and 125 slaves) on 1200 meter (4000 feet) cable.

The use of drop cable connection (i.e. T-connection) is not allowed in a BACnet MS/TP system. Drop cables will lead to reflection and malfunction of the system. In location where the cabling will demand a T-connection the use of repeaters is recommended.

Note that a repeater is a node in both of the two segments it connects. The number of frequency converters is based on a single master system. If there are two or more devices (e.g. PC tools, Routers), the number of frequency converters must be reduced correspondingly.

- Maximum length of an MS/TP segment: 1200 meters (4000 feet)
- Characteristic impedance: 100 to 130Ω
- Resistance: <math><110\Omega/\text{km}</math>
- Distributed capacitance: <math><100\text{pF}/\text{m}</math>, between conductors
- Cross section: 0.82mm<sup>2</sup> conductor area, corresponding to AWG 18
- Cable type: twisted in pairs, 1 x 2, or 2 x 2 wires
- Screening: Copper-braided screen or braided screen and foil screen

Use of the same cable type throughout the entire segment is recommended to avoid impedance mismatch.



TM090409

## 3.2 Network connection

Connect the frequency converter to the RS-485 network as follows (see also diagram):

1. Connect signal wires to terminal 68 (P+) and terminal 69 (N-) on the main control board of the frequency converter.
2. Connect the cable screen as described under chapter Bus Cabling.




Screened, twisted-pair cables are recommended to reduce noise between conductors.

## 3.3 Network termination

### Maximum cable lengths

Maximum total bus cable length: 4000 feet ~ 1200m



TM090410

## 3.4 Switches S201, S202, and S801


Switches S201 (A53) and S202 (A54) are used to select a current (0-20mA) or a voltage (-10 to 10V) configuration of the analog input terminals 53 and 54 respectively.

Switch S801 (BUS TER.) can be used to enable termination on the RS-485 port (terminals 68 and 69).

**Default setting:**

- S201 (A53) = OFF (voltage input)
- S202 (A54) = OFF (voltage input)
- S801 (Bus termination) = OFF

When changing the function of S201, S202 or S801 be careful not to use force for the switch over. It is recommended to remove the LCP fixture (cradle) when operating the switches. The switches must not be operated with power on the frequency converter.




TM090411

**3.5 Cable routing**

The BACnet communication cable must be kept away from motor cables to avoid coupling of high frequency noise from one cable to the other. Normally a distance of 200 mm is sufficient, but maintaining the greatest possible distance between cables is generally recommended, especially where cables run in parallel over long distances.

When crossing is unavoidable, the BACnet cable must cross motor cable at an angle of 90°.



TM090412

**4. Bus cabling**

**4.1 EMC precautions**

The following EMC precautions are recommended to achieve interference-free operation of the BACnet network.

Ensure compliance with relevant national and local regulations, for example in protective earth connection.

**4.2 Single ground shielding**

For installing the bus cable on MS/TP, two different strategies can be followed, Single ground of shield and multiple ground of shield. Each strategy has both advantages and disadvantages. The following chapter explains the different between the two strategies.

The single ground shield is specified in the ANSI/ASRAHE 135-2004 standard. The solution benefits by having only one ground connection of the shield, by doing so the possibility for ground loop of equalizing current is heavily reduced.

In these systems the shield of the MS/TP cables has to be isolated from ground at all stations, except one. At each station the shield from the two cables has to be connected with each other, and isolated from ground. The best solution for this has been proven to be the use of shrink tubes.

The single ground shielding is a good approach where the system uses long bus cables. If two buildings have to be connected over the same MS/TP bus cable, the use of fibre optic has to be considered. This will prevent that a lightning stroke will be carried from one building to another, and problem with difference in earth potential can be neglected.

**4.3 Multiple ground shielding**

If the distance between the individual drives is limited (e.g. inside a cabinet or in one control room) Grundfos recommends connecting the screen to ground at both ends of the bus cable. This ensures the maximum protection from EMC noise.

Connecting the screen at each end will require that each BACnet device has the same earth potential or an equalizing current will flow in the screen of the cable and cause disturbance and poor performance of the system.

Low impedance to ground connection of the screen can be achieved by connecting the surface of the screen to ground, by means of a cable clamp or a conductive cable gland.

**5. System configuration**

**5.1 Configuring BACnet**

**Initialization procedure**

**General settings**

| Parameter                     | Default value            | Setting for BACnet             |
|-------------------------------|--------------------------|--------------------------------|
| 8-01 Control Site             | Digital and control word | Digital and control word       |
| 8-02 Control Source           | FC port                  | FC port                        |
| 8-03 Control Timeout Time     | 60 sec                   | Depending on your application. |
| 8-04 Control Timeout Function | Off                      | Depending on your application. |
| 8-05 End-of-Timeout Function  | Resume setup             | Depending on your application. |
| 8-06 Reset Control Timeout    | Do not reset             | Depending on your application. |
| 8-07 Diagnosis Trigger        | Disable                  | N/A                            |
| 8-09 Communication Charset    | ANSI X3.4                | -                              |
| 8-10 Control Profile          | FC Profile               | Depending on the BMS system    |

## FC port settings

| Parameter                   | Default value | Setting for BACnet |
|-----------------------------|---------------|--------------------|
| 8-30 Protocol               | FC            | BACnet             |
| 8-31 Address                | 1             | 1 <sup>1)</sup>    |
| 8-32 Baud Rate              | 9600          | 9600 baud          |
| 8-35 Minimum Response Delay | 10 ms         | 10 ms              |
| 8-36 Maximum Response Delay | 5000 ms       | 5000 ms            |

1) The address setting is depending on the system and each device connected to the BACnet MS/TP must have a unique address on this MS/TP network.

## Digital/Bus Settings

| Parameter                    | Default value | Setting for BACnet |
|------------------------------|---------------|--------------------|
| 8-50 Coasting Select         | Logic-or      | Logic-or           |
| 8-52 DC Brake Select         | Logic-or      | Logic-or           |
| 8-53 Start Select            | Logic-or      | Logic-or           |
| 8-54 Reversing Select        | Logic-or      | Logic-or           |
| 8-55 Set-up Select           | Logic-or      | Logic-or           |
| 8-56 Preset Reference Select | Logic-or      | Logic-or           |

## BACnet Settings

| Name                         | Default value | Setting for BACnet                               |
|------------------------------|---------------|--|
| 8-70 BACnet Device Instance  | 1             | 1 <sup>2)</sup>                                  |
| 8-72 MS/TP Max Masters       | 127           | Dependent on the Number of Masters in the system |
| 8-74 I-Am Service            | At power up   | At power up                                      |
| 8-75 Initialisation Password | admin         | admin  |

2) The device instance setting is depending on the system, and each device connected to the BACnet MS/TP must have a unique device instance in the complete system.

## Related information

[7.1 Parameter list](#)

## 5.2 Control word time-out function

8-03 Control Timeout Time and 8-04 Control Timeout Function are not enabled in this version of the BACnet option.

## 5.3 Example of a simple setup of BACnet

This example shows the necessary steps to set up the CUE BACnet interface with the following system requirements:

- MS/TP running at 38,400 Baud
- MAC address 20 for the CUE on the MS/TP network
- Device Instance number 1025 for the CUE
- Highest number of a Master device is 35
- Start/stop of FC from BACnet only
- Reference from BACnet
- Read status of FC (Actual speed)

### Set the following parameters:

| Parameter                   | Value           |
|-----------------------------|-----------------|
| 8-30 Protocol               | BACnet [5]      |
| 8-31 Address                | 20              |
| 8-32 Baud Rate              | 38.400 Baud [4] |
| 8-50 Coasting Select        | Bus [1]         |
| 8-70 BACnet Device Instance | 1025            |
| 8-72 MS/TP Max Masters      | 35              |

After the parameters have been set according the table above, the drive has to be unpowered and repowered before the changes take effect. When the frequency converter is detected by the BMS, the

drive can be controlled by BV:1, which will start the motor if set to [1]. Setting AV:1 will set the speed reference of the drive. The actual speed can be monitored via AV:3.

## Related information

[6.1 Analog input and output objects](#)

[6.1.1 Fault codes](#)

## 6. BACnet objects

### 6.1 Analog input and output objects

Control the frequency converter from the BACnet network using objects. The various types of objects and their descriptions are shown in the following tables. In the following tables all available objects are shown. The availability of objects depends on the mounting of the B and/or C options.

#### Analog inputs object map

| ID   | Object name     |           | Present value |        |  |
|------|-----------------|-----------|---------------|--------|--|
|      | Default name    | Parameter | Unit          | Option |  |
| AI:0 | Analog Input 53 | 1662      | %             | -      |  |
| AI:1 | Analog Input 54 | 1664      | %             | -      |  |

#### Analog outputs

| ID   | Object name                    |           |      | Present value |             |         |        |
|------|--------------------------------|-----------|------|---------------|-------------|---------|--------|
|      | Default name                   | Parameter | Unit | Writeable     | Commandable | Timeout | Option |
| AO:0 | Terminal 42 Output Bus Control | 653       | %    | x             | x           | x       | -      |

#### Analog values

| ID    | Object name              |           |        |                    | Present value |           |             |         |        |
|-------|--------------------------|-----------|--------|--------------------|---------------|-----------|-------------|---------|--------|
|       | Default name             | Writeable | EEPROM | Parameter          | Unit          | Writeable | Commandable | Timeout | Option |
| AV:0  | Reserved for VFD profile |           |        |                    |               |           |             |         |        |
| AV:1  | Input reference 1        | x         | x      | Note <sup>3)</sup> | %             | x         | x           | x       | -      |
| AV:2  | Input reference 2        | -         | -      | Note <sup>3)</sup> | %             | x         | x           | x       | -      |
| AV:3  | Output speed             | x         | x      | Note <sup>4)</sup> | %             | -         | -           | -       | -      |
| AV:4  | PID feedback             | -         | -      | Note <sup>5)</sup> | %             | -         | -           | -       | -      |
| AV:5  | Motor current            | x         | x      | 1614               | Amps          | -         | -           | -       | -      |
| AV:6  | Power                    | x         | x      | 1610               | kW            | -         | -           | -       | -      |
| AV:7  |                          |           |        |                    |               |           |             |         |        |
| AV:8  |                          |           |        |                    |               |           |             |         |        |
| AV:9  |                          |           |        |                    |               |           |             |         |        |
| AV:10 | Reserved for VFD profile |           |        |                    |               |           |             |         |        |
| AV:11 |                          |           |        |                    |               |           |             |         |        |
| AV:12 |                          |           |        |                    |               |           |             |         |        |
| AV:13 |                          |           |        |                    |               |           |             |         |        |
| AV:14 |                          |           |        |                    |               |           |             |         |        |
| AV:15 | Motor thermal            | -         | -      | 1618               | %             | -         | -           | -       | -      |
| AV:16 |                          |           |        |                    |               |           |             |         |        |
| AV:17 |                          |           |        |                    |               |           |             |         |        |
| AV:18 | Reserved for VFD profile |           |        |                    |               |           |             |         |        |
| AV:19 |                          |           |        |                    |               |           |             |         |        |
| AV:20 |                          |           |        |                    |               |           |             |         |        |
| AV:21 | Operating hours          | -         | -      | 1500               | Hours         | -         | -           | -       | -      |
| AV:22 | Running hours            | -         | -      | 1501               | Hours         | -         | -           | -       | -      |
| AV:23 | kWh counter              | -         | -      | 1502               | kWh           | -         | -           | -       | -      |
| AV:24 | Motor voltage            | -         | -      | 1612               | V             | -         | -           | -       | -      |
| AV:25 | Frequency                | -         | -      | 1613               | Hz            | -         | -           | -       | -      |
| AV:26 | Torque                   | -         | -      | 1622               | %             | -         | -           | -       | -      |
| AV:27 | DC Link voltage          | -         | -      | 1630               | V             | -         | -           | -       | -      |
| AV:28 | Heatsink temperature     | -         | -      | 1634               | Deg.          | -         | -           | -       | -      |
| AV:29 | Inverter thermal         | -         | -      | 1635               | %             | -         | -           | -       | -      |
| AV:30 | Setpoint 1               | -         | -      | 2021               | %             | x         | -           | -       | -      |
| AV:31 | Bus feedback 1           | -         | -      | 894                | %             | x         | -           | -       | -      |
| AV:32 | Reserved for P, I, D     |           |        |                    |               |           |             |         |        |
| AV:33 |                          |           |        |                    |               |           |             |         |        |

| ID    | Object name                    |           |        |                    |       | Present value |             |         |         |
|-------|--------------------------------|-----------|--------|--------------------|-------|---------------|-------------|---------|---------|
|       | Default name                   | Writeable | EEPROM | Parameter          | Unit  | Writeable     | Commandable | Timeout | Option  |
| AV:34 |                                |           |        |                    |       |               |             |         |         |
| AV:35 | Setpoint 2                     | -         | -      | 2022               | %     | x             | -           | -       | -       |
| AV:36 | Bus feedback 2                 | -         | -      | 895                | %     | x             | -           | -       | -       |
| AV:37 |                                |           |        |                    |       |               |             |         |         |
| AV:38 | Reserved for P, I, D           |           |        |                    |       |               |             |         |         |
| AV:39 |                                |           |        |                    |       |               |             |         |         |
| AV:40 | Setpoint 3                     | -         | -      | 2023               | %     | x             | -           | -       | -       |
| AV:41 | Bus feedback 3                 | -         | -      | 896                | %     | x             | -           | -       | -       |
| AV:42 |                                |           |        |                    |       |               |             |         |         |
| AV:43 | Reserved for P, I, D           |           |        |                    |       |               |             |         |         |
| AV:44 |                                |           |        |                    |       |               |             |         |         |
| AV:45 | Running bypass                 | -         | -      | 3111               | Hours | -             | -           | -       | MCO 104 |
| AV:46 | -                              | -         | -      | -                  | -     | -             | -           | -       | -       |
| AV:47 | -                              | -         | -      | -                  | -     | -             | -           | -       | -       |
| AV:48 | -                              | -         | -      | -                  | -     | -             | -           | -       | -       |
| AV:49 | -                              | -         | -      | -                  | -     | -             | -           | -       | -       |
| AV:50 | Alarm Log: Error Code          | -         | -      | 1530               | NONE  | -             | -           | -       | -       |
| AV:51 | Fault code                     | -         | -      | Note <sup>6)</sup> | NONE  | -             | -           | -       | -       |
| AV:52 | PID Start speed                | -         | -      | 2083               | Hz    | x             | -           | -       | -       |
| AV:53 | On reference bandwidth         | -         | -      | 2084               | %     | x             | -           | -       | -       |
| AV:54 | PID proportional gain          | -         | -      | 2093               | NONE  | x             | -           | -       | -       |
| AV:55 | PID Integral time              | -         | -      | 2094               | Sec   | x             | -           | -       | -       |
| AV:56 | PID Differentiation time       | -         | -      | 2095               | Sec   | x             | -           | -       | -       |
| AV:57 | PID Differentiation gain limit | -         | -      | 2096               | NONE  | x             | -           | -       | -       |

<sup>3)</sup> Either AV:1 or AV:2 controls the drive reference. Only one of them can control the frequency converter at a time and BV:2 decides which one.

<sup>4)</sup> This value is not directly available in the frequency converter. The value must be calculated as follows:  $AV \# 3 = \frac{Par. 16 - 17}{Par. 4 - 13} \times 100 \%$

<sup>5)</sup> This value is not directly available in the frequency converter. The value must be calculated as follows:  $AV \# 4 = \frac{Par. 16 - 52}{Par. 20 - 14} \times 100 \%$

<sup>6)</sup> CUE fault codes are transmitted as an analog value in AV:51. The fault codes are mapped and the CUE alarm codes are shown as well for comparison.

## Related information

[6.1.1 Fault codes](#)

[8.2 Alarm words](#)

### 6.1.1 Fault codes

The following table shows the mapping of the CUE alarm codes and their mapping to the BACnet's fault codes.

#### Mapping of fault codes

| Fault                | Fault codes | CUE Alarms                        | Fault descriptions   |
|----------------------|-------------|-----------------------------------|--|
| Communication error  | 1           | 17, 34                            | Loss of communication with the network                                       |
| Over current         | 2           | 13, 40, 41, 42, 59                | Instantaneous Output Current has exceeded inverter rated or programmed value |
| Over temperature     | 3           | 11, 29, 65, 69, 74, 244, 245, 247 | Heat sink Temperature Limit has been reached                                 |
| Over speed deviation | 4           | 49, 62                            | Inverter has exceeded maximum or programmed limit                            |
| Over voltage         | 5           | 5, 7, 64                          | DC Bus Voltage has exceeded inverter limit                                   |
| Under voltage        | 6           | 1, 6, 8                           | DC Bus Voltage is lower than required inverter limit                         |

| Fault                    | Fault codes | CUE Alarms                         | Fault descriptions   |
|--------------------------|-------------|------------------------------------|--|
| Short circuit            | 7           | 16                                 | Inverter Output has shorted Phase to Phase   |
| Ground fault             | 8           | 14                                 | Inverter Output Grounding Current has exceeded manufacturer  |
| Motor overload           | 9           | 10, 50-58, 222                     | Motor is overloaded  |
| Inverter overload        | 10          | 9                                  | Timed over current fault   |
| Over torque detection    | 11          | 12                                 | Programmed limit for torque has been exceeded  |
| External fault           | 12          | 142                                | External fault has been activated in the inverter. This is a hard fault that must be reset                         |
| Operator interface error | 13          | -                                  | Inverter programming or operational interface malfunction  |
| Load loss                | 14          | 3, 95, 229                         | Load on the Motor is less than programmed limit of system. An Example is a broken belt or coupling                 |
| Configuration error      | 15          | 70, 76, 79, 81, 82, 91             | Errors exist in the programmed or operational configuration of the inverter  |
| Feedback failure         | 16          | 60, 90, 192                        | Required system operational feedback (signal or sensor) is not responding as expected for correct system operation |
| Output phase loss        | 17          | 30, 31, 32                         | One or more of the output phases from the inverter to the motor are open   |
| Motor stall              | 18          | 99                                 | Motor is operating in stall region and not able to accelerate  |
| Power unit error         | 19          | 4, 33, 36, 37, 46, 228, 246        | Error sensed on the power section of the inverter  |
| Input phase              | 20          | -                                  | Input single phase or low line voltage condition   |
| Internal drive failure   | 21          | 23, 27, 38, 39, 47, 48, 73, 85, 86 | CUE specific fault   |

## 6.2 Binary input and output objects

### Binary inputs

| ID            | Object name                    |           | Present value |        |  |
|---------------|--------------------------------|-----------|---------------|--------|--|
|               | Default name                   | Parameter | Bit number    | Option |  |
| BI:0          | Digital input Term 33          | 1660      | 0             | -      |  |
| BI:1          | Digital input Term 32          | 1660      | 1             | -      |  |
| BI:2          | Digital input Term 29          | 1660      | 2             | -      |  |
| BI:3          | Digital input Term 27          | 1660      | 3             | -      |  |
| BI:4          | Digital input Term 19          | 1660      | 4             | -      |  |
| BI:5          | Digital input Term 18          | 1660      | 5             | -      |  |
| BI:6          | Digital input Term 37          | 1660      | 6             | -      |  |
| BI:10 - BI:15 | Reserved for P1660/x (MCB 115) |           |               |        |  |

### Binary outputs

| ID           | Object name                          |           |            | Present value |             |         |        |
|--------------|--------------------------------------|-----------|------------|---------------|-------------|---------|--------|
|              | Default name                         | Parameter | Bit number | Writeable     | Commandable | Timeout | Option |
| BO:0         | Digital Output Term 27               | 590       | 0          | x             | x           | x       | -      |
| BO:1         | Digital Output Term 29               | 590       | 1          | x             | x           | x       | -      |
| BO:4         | Relay 1                              | 590       | 4          | x             | x           | x       | -      |
| BO:5         | Relay 2                              | 590       | 5          | x             | x           | x       | -      |
| BO:9 - BO:39 | Reserved for Output P590/x (MCB 115) |           |            |               |             |         |        |

### Binary values

| ID   | Object name              |           |        |                            | Present value       |           |             |        |         |        |
|------|--------------------------|-----------|--------|----------------------------|---------------------|-----------|-------------|--------|---------|--------|
|      | Default name             | Writeable | EEPROM | Parameter                  | Bit number          | Writeable | Commandable | EEPROM | Timeout | Option |
| BV:0 | Reserved for VFD profile |           |        |                            |                     |           |             |        |         |        |
| BV:1 | RUN/STOP Command         | x         | x      | CTW=047c<br>+<br>Reversing | 6 reverse<br>bit 15 | x         | x           | -      | x       | -      |

| ID    | Object name                                |           |        |           |            | Present value |             |        |         |         |
|-------|--|-----------|--------|-----------|------------|---------------|-------------|--------|---------|---------|
|       | Default name                               | Writeable | EEPROM | Parameter | Bit number | Writeable     | Commandable | EEPROM | Timeout | Option  |
| BV:2  | REF 1 / REF 2 Select                       | x         | x      | Note 1    | n/a        | x             | x           | x      | x       |         |
| BV:3  | Fault Reset Command                        | x         | x      | CTW       | 7          | x             | -           | -      | -       | -       |
| BV:4  | RUN / STOP Monitor                         | x         | x      | STW       | 1          | -             | -           | -      | -       | -       |
| BV:5  | OK / FAULT Monitor                         | x         | x      | STW       | 3, 6, 7    | -             | -           | -      | -       | -       |
| BV:6  | HAND / AUTO Reference                      | x         | x      | 16-95     | 1          | -             | -           | -      | -       | -       |
| BV:7  |  |           |        |           |            |               |             |        |         |         |
| BV:8  |  |           |        |           |            |               |             |        |         |         |
| BV:9  |  |           |        |           |            |               |             |        |         |         |
| BV:10 |  |           |        |           |            |               |             |        |         |         |
| BV:11 |  |           |        |           |            |               |             |        |         |         |
| BV:12 |  |           |        |           |            |               |             |        |         |         |
| BV:13 | Reserved for VFD profile                   |           |        |           |            |               |             |        |         |         |
| BV:14 |  |           |        |           |            |               |             |        |         |         |
| BV:15 |  |           |        |           |            |               |             |        |         |         |
| BV:16 |  |           |        |           |            |               |             |        |         |         |
| BV:17 |  |           |        |           |            |               |             |        |         |         |
| BV:18 |  |           |        |           |            |               |             |        |         |         |
| BV:19 |  |           |        |           |            |               |             |        |         |         |
| BV:20 |  |           |        |           |            |               |             |        |         |         |
| BV:21 | Warning                                    | x         | x      | STW       | 7          | -             | -           | -      | -       | -       |
| BV:22 | Trip                                       | x         | x      | STW       | 3          | -             | -           | -      | -       | -       |
| BV:23 | Trip lock                                  | -         | -      | STW       | 6          | -             | -           | -      | -       | -       |
| BV:24 | Coasting                                   | -         | -      | CTW       | 3          | x             | x           | -      | x       | -       |
| BV:25 | CW/CCW                                     | -         | -      | CTW       | 15         | x             | x           | -      | x       | -       |
| BV:26 | Jog  | -         | -      | CTW       | 8          | x             | x           | -      | x       | -       |
| BV:27 | Reset                                      | -         | -      | CTW       | 7          | x             | x           | -      | x       | -       |
| BV:28 | Reset KWh Counter                          | -         | -      | 1506      | n/a        | x             | -           | -      | -       | -       |
| BV:29 | Reset Running hours counter                | -         | -      | 1507      | n/a        | x             | -           | -      | -       | -       |
| BV:30 | Reverse                                    | -         | -      | STW       | 1          | -             | -           | -      | -       | -       |
| BV:31 | Speed = reference                          | -         | -      | STW       | 8          | -             | -           | -      | -       | -       |
| BV:32 | Bus control                                | -         | -      | STW       | 9          | -             | -           | -      | -       | -       |
| BV:33 | Running                                    | x         | x      | STW       | 11         | -             | -           | -      | -       | -       |
| BV:34 | Ramp 1/ Ramp 2                             | -         | -      | CTW       | 9          | x             | x           | -      | -       | -       |
| BV:35 | ECB Test mode                              | -         | -      | 3110      | 0          | -             | -           | -      | -       | MCO 104 |
| BV:36 | ECB Drive mode                             | -         | -      | 3110      | 1          | -             | -           | -      | -       | MCO 104 |
| BV:37 | ECB auto. Bypass enable                    | -         | -      | 3110      | 2          | -             | -           | -      | -       | MCO 104 |
| BV:38 | ECB Bypass mode                            | -         | -      | 3110      | 3          | -             | -           | -      | -       | MCO 104 |
| BV:39 |  |           |        |           |            |               |             |        |         |         |
| BV:40 |  |           |        |           |            |               |             |        |         |         |
| BV:41 |  |           |        |           |            |               |             |        |         |         |
| BV:42 | Reserved for ECB (MCO 104) - 3110 bit 4-10 |           |        |           |            |               |             |        |         |         |
| BV:43 |  |           |        |           |            |               |             |        |         |         |
| BV:44 |  |           |        |           |            |               |             |        |         |         |
| BV:45 |  |           |        |           |            |               |             |        |         |         |

### 6.3 Multistate value objects

| ID    | Object name                  | Present value |            |           |          | Timeout |
|-------|------------------------------|---------------|------------|-----------|----------|---------|
|       | Default name                 | Parameter     | Bit number | Writeable | Cmd.able |         |
| MSV:0 | Smart logic controller state | 1638          | n/a        | -         | -        | -       |
| MSV:1 | Active Setup                 | CTW           | 13 and 14  | x         | x        | x       |

### 6.4 Real time clock variable

The frequency converter has a built-in real-time clock. The standard real-time clock has no battery backup function, which will lead to a loss of time if the drive is un-powered.

Some BACnet Masters can be programmed to send out the date and time as a Broadcast Telegram on a regular basis. The BACnet Interface will update the real-time clock of the drive if it receives the time synchronization telegram.

### 6.5 Feedback to network

The BACnet option provides several output variables (nvo's) objects to the network, containing important -, motor- and I/O feedback data. The BACnet option transmits bound network variables only and sends feedback data when the value changes.

Influence of the digital input terminals upon the Control Mode, 8-50 Coasting Select to 8-56 Preset Reference Select The influence of the digital input terminals upon control of the frequency converter can be programmed in 8-50 Coasting Select to 8-56 Preset Reference Select.

### 6.7 Object/property support matrix

#### Object types and properties

| Property                      | Device | Binary input | Binary output | Binary value | Analog input | Analog output | Analog value | Multistage value |
|-------------------------------|--------|--------------|---------------|--------------|--------------|---------------|--------------|------------------|
| Object identifier             | x      | x            | x             | x            | x            | x             | x            | x                |
| Object name                   | x      | x            | x             | x            | x            | x             | x            | x                |
| Object type                   | x      | x            | x             | x            | x            | x             | x            | x                |
| System status                 | x      | -            | -             | -            | -            | -             | -            | -                |
| Vendor name                   | x      | -            | -             | -            | -            | -             | -            | -                |
| Vendor identifier             | x      | -            | -             | -            | -            | -             | -            | -                |
| Model name                    | x      | -            | -             | -            | -            | -             | -            | -                |
| Firmware revision             | x      | -            | -             | -            | -            | -             | -            | -                |
| Application software revision | x      | -            | -             | -            | -            | -             | -            | -                |
| Location                      | x      | -            | -             | -            | -            | -             | -            | -                |
| Description                   | x      | -            | -             | -            | -            | -             | -            | -                |
| Protocol version              | x      | -            | -             | -            | -            | -             | -            | -                |
| Protocol revision             | x      | -            | -             | -            | -            | -             | -            | -                |
| Services supported            | x      | -            | -             | -            | -            | -             | -            | -                |
| Object list                   | x      | -            | -             | -            | -            | -             | -            | -                |
| Max. APDU length              | x      | -            | -             | -            | -            | -             | -            | -                |
| Segmentation support          | x      | -            | -             | -            | -            | -             | -            | -                |
| Local time                    | x      | -            | -             | -            | -            | -             | -            | -                |
| Local date                    | x      | -            | -             | -            | -            | -             | -            | -                |
| APDU timeout                  | x      | -            | -             | -            | -            | -             | -            | -                |
| Number APDU retries           | x      | -            | -             | -            | -            | -             | -            | -                |
| Max Master                    | x      | -            | -             | -            | -            | -             | -            | -                |
| Max info frames               | x      | -            | -             | -            | -            | -             | -            | -                |
| Device address binding        | x      | -            | -             | -            | -            | -             | -            | -                |

8-01 Control Site overrides the settings in parameters 8-50 to 8-56 and Terminal 37, Safe Stop overrides any parameter.

Each of the digital input signals can be programmed to logic AND, logic OR, or to have no relation to the corresponding bit in the control word. In this way a specific control command such as Stop or Coast, can be initiated by the fieldbus only, fieldbus AND Digital Input, or Fieldbus OR Digital input terminal.

In order to control the frequency converter via BACnet, 8-50 Coasting Select must be set to either Bus [1], or to Logic AND [2] and 8-01 Control Site must be set to Digital and ctrl. word [0] or Control word only [2].

### 6.6 BIBBs

|                            |          |
|----------------------------|----------|
| ReadProperty               | Execute  |
| WriteProperty              | Execute  |
| DeviceCommunicationControl | Execute  |
| ReinitializeDevice         | Execute  |
| I-Am                       | Initiate |
| I-Have                     | Initiate |
| TimeSynchronization        | Execute  |
| Who-Has                    | Execute  |
| Who-Is                     | Execute  |

| Property           | Device | Binary input | Binary output | Binary value    | Analog input | Analog output | Analog value    | Multistage value |
|--------------------|--------|--------------|---------------|-----------------|--------------|---------------|-----------------|------------------|
| Database revision  | x      | -            | -             | -               | -            | -             | -               | -                |
| Present value      | -      | x            | x             | x               | x            | x             | x               | x                |
| Status flags       | -      | x            | x             | x               | x            | x             | x               | x                |
| Event state        | -      | x            | x             | x               | x            | x             | x               | x                |
| Reliability        | -      | x            | x             | x               | x            | x             | x               | x                |
| Out-of-service     | -      | x            | x             | x               | x            | x             | x               | x                |
| Number of states   | -      | -            | -             | -               | -            | -             | -               | x                |
| State text         | -      | -            | -             | -               | -            | -             | -               | x                |
| Units              | -      | -            | -             | -               | x            | x             | x               | -                |
| Priority array     | -      | -            | x             | x <sup>7)</sup> | -            | x             | x <sup>7)</sup> | x <sup>7)</sup>  |
| Relinquish default | -      | -            | x             | x <sup>7)</sup> | -            | x             | x <sup>7)</sup> | x <sup>7)</sup>  |
| Polarity           | -      | x            | x             |                 | -            | -             | -               | -                |
| Active text        | -      | x            | x             | x               | -            | -             | -               | -                |
| Inactive text      | -      | x            | x             | x               | -            | -             | -               | -                |

7) For commandable values only

## 7. Parameters

### 7.1 Parameter list

#### BACnet specific parameter list

| Parameter                     | Default value           | Range       | Conversion index | Data type |
|-------------------------------|-------------------------|-------------|------------------|-----------|
| 8-01 Control site             | Dig. and ctrl. word [0] | [0 - 2]     | -                | 5         |
| 8-02 Control source           | Option A                | [0 - 4]     | -                | 5         |
| 8-03 Control timeout time     | 1 s                     | 0.1 - 18000 | 1                | 7         |
| 8-04 Control timeout function | Off [0]                 | [0 - 10]    | -                | 5         |
| 8-05 End-of-timeout function  | Hold set-up [0]         | [0 - 1]     | -                | 5         |
| 8-06 Reset control timeout    | Do not reset [0]        | [0 - 1]     | -                | 5         |
| 8-07 Diagnosis trigger        | Disable [0]             | [0 - 3]     | -                | 5         |
| 8-10 Control profile          | FC [0]                  | [0 - x]     | -                | 5         |
| 8-30 Protocol                 | FC                      | -           | -                | -         |
| 8-31 Address                  | 1                       | [0 - 255]   | -                | -         |
| 8-32 Baud rate                | 9600                    | [0 - 7]     | -                | -         |
| 8-33 Parity / Stop bits       | No parity, 1 Stop bit   | -           | -                | -         |
| 8-35 Minimum response delay   | 10 mS                   | -           | -                | -         |
| 8-36 Maximum response delay   | 5000 mS                 | -           | -                | -         |
| 8-37 Maximum inter-char delay | 25.00 mS                | -           | -                | -         |
| 8-50 Coasting select          | Logic OR [3]            | [0 - 3]     | -                | 5         |
| 8-52 DC Brake select          | Logic OR [3]            | [0 - 3]     | -                | 5         |
| 8-53 Start select             | Logic OR [3]            | [0 - 3]     | -                | 5         |
| 8-54 Reversing select         | Logic OR [3]            | [0 - 3]     | -                | 5         |
| 8-55 Set-up select            | Logic OR [3]            | [0 - 3]     | -                | 5         |
| 8-56 Preset reference select  | Logic OR [3]            | [0 - 3]     | -                | 5         |
| 8-70 BACnet Device instance   | 1                       | [1-4194304] | -                | -         |
| 8-72 MS/TP Max masters        | 127                     | [1-127]     | -                | -         |
| 8-73 MS/TP Max info frames    | -                       | -           | -                | -         |
| 8-74 "I-Am" service           | Once at powerup [0]     | [0-1]       | -                | -         |
| 8-75 Initialisation password  | admin                   | String [19] | -                | -         |

The conversion index refers to a conversion figure used when writing or reading to and from the frequency converter.

#### Conversion index

| Conversion index  | 100 | 67   | 6       | 5      | 4     | 3    | 2   | 1  | 0 | -1  | -2   | -3    | -4     | -5      | -6       |
|-------------------|-----|------|---------|--------|-------|------|-----|----|---|-----|------|-------|--------|---------|----------|
| Conversion factor | 1   | 1/60 | 1000000 | 100000 | 10000 | 1000 | 100 | 10 | 1 | 0.1 | 0.01 | 0.001 | 0.0001 | 0.00001 | 0.000001 |

| Data type | Description                          | Type   |
|-----------|--------------------------------------|--------|
| 2         | Integer 8                            | Int8   |
| 3         | Integer 16                           | Int16  |
| 4         | Integer 32                           | Int32  |
| 5         | Unsigned 8                           | UInt8  |
| 6         | Unsigned 16                          | UInt16 |
| 7         | Unsigned 32                          | UInt32 |
| 9         | Visible string                       | VisStr |
| 33        | Normalized value 2 bytes             | N2     |
| 35        | Bit sequence of 16 boolean variables | V2     |
| 54        | Time difference w/o date             | TimD   |

## 7.2 Parameter description

### 8-xx commands and options

#### 8-01 Control site

| Option | Function  |
|--------|---|
|        | The setting in this parameter overrides the settings in 8-50 Coasting select to 8-56 Preset reference select. |
| [0]    | Digital and control word<br>Control by using both digital input and control word.                             |
| [1]    | Digital only<br>Control by using digital inputs only.   |
| [2]    | Control word only<br>Control by using control word only.  |

#### 8-02 Control source

| Option | Function   |
|--------|--|
|        | Select the source of the control word: one of two serial interfaces or four installed options. During initial power-up, the frequency converter automatically sets this parameter to Option A [3] if it detects a valid fieldbus option installed in slot A. If the option is removed, the frequency converter detects a change in the configuration, sets 8-02 Control Source back to default setting FC Port, and the frequency converter then trips. If an option is installed after initial power-up, the setting of 8-02 Control Source will not change but the frequency converter will trip and display: Alarm 67 Option changed. |
| [0]    | None   |
| [1]    | FC Port  |
| [2]    | USB Port   |
| [3]    | Option A   |
| [4]    | Option B   |

This parameter cannot be adjusted while the motor is running.

#### 8-03 Control timeout time

| Range           | Function   |
|-----------------|--|
| 0 s             | Enter the maximum time expected to pass between the reception of two consecutive telegrams. If this time is exceeded, it indicates that the serial communication has stopped. The function selected in 8-04 Control timeout function will then be carried out. |
| [0.1 - 18000 s] |  |

| Range | Function   |
|-------|--|
|       | In BACnet the following variables will trigger the Control word time parameter:<br>Analog outputs<br>Binary outputs<br>AV0<br>AV1<br>AV2<br>AV4<br>BV1<br>BV2<br>BV3<br>BV4<br>BV5<br>Multistate outputs |

#### 8-04 Control timeout function

| Option | Function   |
|--------|--|
|        | Select the time-out function. The timeout function is activated when the control word fails to be updated within the time period specified in 8-03 Control timeout time. Choice [20] only appears after setting the Metasys N2 protocol. |
| [0]    | Off  |
| [1]    | Freeze output  |
| [2]    | Stop   |
| [3]    | Jogging  |
| [4]    | Max. speed   |
| [5]    | Stop and trip  |
| [7]    | Select setup 1   |
| [8]    | Select setup 2   |
| [9]    | Select setup 3   |
| [10]   | Select setup 4   |
| [20]   | N2 override release  |

#### 8-05 End-of-timeout function

| Option | Function  |
|--------|---|
|        | Select the action after receiving a valid control word following a time-out. This parameter is active only when 8-04 Control timeout function is set to [Set-up 1-4].                                   |
| [0]    | Hold set-up<br>Retains the set-up selected in 8-04 Control timeout function and displays a warning, until 8-06 Reset control timeout toggles. Then the frequency converter resumes its original set-up. |
| [1]    | Resume setup<br>Resumes the set-up active prior to the timeout.   |

**8-06 Reset control timeout**

| Option           | Function  |
|------------------|---|
|                  | This parameter is active only when the choice Hold set-up [0] has been selected in 8-05 End-of-timeout function .   |
| [0] Do not reset | Retains the set-up specified in 8-04 Control timeout function, [Select setup 1-4] following a control time-out.   |
| [1] Do reset     | Returns the frequency converter to the original set-up following a control word time-out. When the value is set to Do reset [1], the frequency converter performs the reset and then immediately reverts to the Do not reset [0] setting. |

**8-07 Diagnosis trigger**

| Option                       | Function                                   |
|------------------------------|--|
|                              | This parameter has no function for BACnet. |
| [0] Disable                  |  |
| [1] Trigger on alarms        |  |
| [2] Trigger alarm or warning |  |

**8-09 Communication charset**

| Option         | Function |
|----------------|----------|
| [0] ISO 8859-1 | -        |
| [1] ANSI X3.4  | -        |

**8-30 Protocol**

| Option     | Function   |
|------------|--|
| [5] BACnet | The BACnet protocol is an international protocol that efficiently integrates all parts of building automation equipment from the actuator level to the building management system. |

**8-32 Baud rate**

| Option         | Function  |
|----------------|---|
|                | Baud rate selection depends on Protocol selection in 8-30 Protocol. |
| [2] 9600 Baud  |   |
| [3] 19200 Baud |   |
| [4] 38400 Baud |   |
| [6] 76800 Baud |   |

Default refers to the FC Protocol.

**8-33 Parity / Stop bits**

| Option                      | Function   |
|-----------------------------|--|
|                             | Parity and Stop bits for the protocol 8-30 Protocol using the FC Port. For some of the protocols, not all options will be visible. Default depends on the protocol selected. |
| [0] Even parity, 1 Stop bit |  |
| [1] Odd parity, 1 Stop bit  |  |
| [2] No parity, 1 Stop bit   |  |
| [3] No parity, 2 Stop bits  |  |

**8-35 Minimum response delay**

| Range                       | Function   |
|-----------------------------|--|
| Size related [5 - 10000 ms] | Specify the minimum delay time between receiving a request and transmitting a response. This is used for overcoming modem turnaround delays. |

**8-36 Maximum response delay**

| Range                        | Function  |
|------------------------------|---|
| Size related [11 - 10001 ms] | Specify the maximum permissible delay time between transmitting a request and receiving a response. Exceeding this delay time will cause control word time-out. |

**8-37 Maximum inter-char delay**

| Range                          | Function   |
|--------------------------------|--|
| Size related [0.00 - 35.00 ms] | Specify the maximum permissible time interval between receipt of two bytes. This parameter activates timeout if transmission is interrupted. |

**8-50 Coasting select**

| Option            | Function  |
|-------------------|---|
|                   | Select control of the coasting function via the terminals (digital input) and/or via the bus.                       |
| [0] Digital input | Activates Start command via a digital input.  |
| [1] Bus           | Activates Start command via the serial communication port or fieldbus option.                                       |
| [2] Logic AND     | Activates Start command via the fieldbus/serial communication port, AND additionally via one of the digital inputs. |
| [3] Logic OR      | Activates Start command via the fieldbus/serial communication port OR via one of the digital inputs.                |

**8-52 DC Brake select**

| Option |               | Function  |
|--------|---------------|---|
|        |               | Select control of the DC brake via the terminals (digital input) and/or via the fieldbus.                           |
| [0]    | Digital input | Activates Start command via a digital input.  |
| [1]    | Bus           | Activates Start command via the serial communication port or fieldbus option.                                       |
| [2]    | Logic AND     | Activates Start command via the fieldbus/serial communication port, AND additionally via one of the digital inputs. |
| [3]    | Logic OR      | Activates Start command via the fieldbus/serial communication port OR via one of the digital inputs.                |

**8-53 Start select**

| Option |               | Function  |
|--------|---------------|---|
|        |               | Select control of the frequency converter start function via the terminals (digital input) and/or via the fieldbus. |
| [0]    | Digital input | Activates Start command via a digital input.  |
| [1]    | Bus           | Activates Start command via the serial communication port or fieldbus option.                                       |
| [2]    | Logic AND     | Activates Start command via the fieldbus/serial communication port, AND additionally via one of the digital inputs. |
| [3]    | Logic OR      | Activates Start command via the fieldbus/serial communication port OR via one of the digital inputs.                |

**8-54 Reversing select**

| Option |               | Function   |
|--------|---------------|--|
|        |               | Select control of the frequency converter reverse function via the terminals (digital input) and/or via the fieldbus.  |
| [0]    | Digital input | Activates Reverse command via a digital input.   |
| [1]    | Bus           | Activates Reverse command via the serial communication port or fieldbus option.  |
| [2]    | Logic AND     | Activates Reverse command via the fieldbus/ serial communication port, AND additionally via one of the digital inputs. |
| [3]    | Logic OR      | Activates Reverse command via the fieldbus/ serial communication port OR via one of the digital inputs.                |

This parameter is active only when 8-01 Control site is set to [0] Digital and control word.

**8-55 Set-up select**

| Option |               | Function  |
|--------|---------------|---|
|        |               | Select control of the frequency converter set-up selection via the terminals (digital input) and/or via the fieldbus.       |
| [0]    | Digital input | Activates the set-up selection via a digital input.   |
| [1]    | Bus           | Activates the set-up selection via the serial communication port or fieldbus option.  |
| [2]    | Logic AND     | Activates the set-up selection via the fieldbus/ serial communication port, AND additionally via one of the digital inputs. |
| [3]    | Logic OR      | Activate the set-up selection via the fieldbus/ serial communication port OR via one of the digital inputs.                 |

**8-56 Preset reference select**

| Option |               | Function   |
|--------|---------------|--|
|        |               | Select control of the frequency converter Preset reference selection via the terminals (digital input) and/or via the fieldbus.  |
| [0]    | Digital input | Activates Preset reference selection via a digital input.  |
| [1]    | Bus           | Activates Preset reference selection via the serial communication port or fieldbus option.                                       |
| [2]    | Logic AND     | Activates Preset reference selection via the fieldbus/serial communication port, AND additionally via one of the digital inputs. |
| [3]    | Logic OR      | Activates the Preset reference selection via the fieldbus/serial communication port OR via one of the digital inputs.            |

**8-70 BACnet device instance**

| Range |               | Function   |
|-------|---------------|--|
|       |               | The Device Instance number must be unique for the complete BACnet, not only for this MS/TP Branch. |
| [1]   | [0 - 4194302] | Enter a unique ID number for the BACnet device.  |

**8-72 MS/TP Max masters**

| Option    | Function   |
|-----------|--|
| [0 - 127] | Define the address of the master which holds the highest address in this network. Decreasing this value optimises polling for the token. |

**8-73 MS/TP Max info frames**

| Range           | Function  |
|-----------------|---|
| [1] [1 - 65534] | Define how many info/data frames the device is allowed to send while holding the token. |

**8-74 I-Am service**

| Option               | Function   |
|----------------------|--|
| [0] Send at power-up |  |
| [1] Continuously     | Choose whether the device should send the I-Am service message only at power-up or continuously with an interval of approx. 1 min. |

**8-75 Initialisation password**

| Range          | Function  |
|----------------|---|
| [Size related] |   |
| [0] [0 - 0]    | Enter the password needed for execution of Drive re-initialisation from BACnet. |

## 8. Troubleshooting

### 8.1 Alarm, warning and extended status

#### Alarm and warning messages

##### General

There is a clear distinction between alarms and warnings. In the event of an alarm, the frequency converter will enter a fault condition. After the cause for the alarm has been cleared, the master must acknowledge the alarm message in order to start operation of the frequency converter again. A warning, on the other hand, may appear when a warning condition arises, then disappear when conditions return to normal without interfering with the process.

Alarm word and Warning word are shown on the display in Hex format. If there is more than one warning or alarm, a sum of all warnings or alarms will be shown. Warning word and Alarm word are displayed in par. 16-90 to 16-95.

For more information on the individual alarms and warnings, please refer to the CUE Service Instructions.

##### Alarms

Following an alarm message the frequency converter will enter a fault condition. Only after the fault has been rectified and the master has acknowledged the alarm message by setting bit 3 in the Control word, can the FC resume operation. All alarms within the FC are represented by a single bit within an Alarm word. An Alarm word is always an action parameter. Bit status FALSE [0] means no alarm, while bit status TRUE [1] means alarm.

##### Warnings

All warnings within the frequency converter are represented by a single bit within a Warning word. A Warning word is always an action parameter. Bit status FALSE [0] means no warning, while bit status TRUE [1] means warning. Each bit status has a corresponding text string message. In addition to the Warning word message the master will also be notified via a change to bit 7 in the status word.

### 8.2 Alarm words

#### Alarm words, 16-90

| Bit (Hex) | Alarm words                       |
|-----------|-----------------------------------|
| 00000001  | Brake check                       |
| 00000002  | Power card over temperature       |
| 00000004  | Earth fault                       |
| 00000008  | Control card over temperature     |
| 00000010  | Control word timeout              |
| 00000020  | Over current                      |
| 00000040  | Torque limit                      |
| 00000080  | Motor thermistor over temperature |
| 00000100  | Motor ETR over temperature        |
| 00000200  | Inverter overloaded               |
| 00000400  | DC link under voltage             |
| 00000800  | DC link over voltage              |
| 00001000  | Short circuit                     |
| 00002000  | Inrush fault                      |
| 00004000  | Mains phase loss                  |
| 00008000  | AMA not OK                        |
| 00010000  | Live zero error                   |
| 00020000  | Internal fault                    |
| 00040000  | Brake overload                    |
| 00080000  | Motor phase U is missing          |
| 00100000  | Motor phase V is missing          |
| 00200000  | Motor phase W is missing          |
| 00400000  | Fieldbus fault                    |
| 00800000  | 24 V supply fault                 |
| 01000000  | Mains failure                     |
| 02000000  | 1.8 V supply fault                |

| Bit (Hex) | Alarm words                  |
|-----------|------------------------------|
| 04000000  | Brake resistor short circuit |
| 08000000  | Brake chopper fault          |
| 10000000  | Option change                |
| 20000000  | Drive initialised            |
| 40000000  | Safe Stop                    |
| 80000000  | Not used                     |

#### Alarm words, 16-91

| Bit (Hex) | Alarm words                          |
|-----------|--------------------------------------|
| 00000001  | Service Trip, read / write           |
| 00000002  | Reserved                             |
| 00000004  | Service Trip, type code / spare part |
| 00000008  | Reserved                             |
| 00000010  | Reserved                             |
| 00000020  | No flow                              |
| 00000040  | Dry pump                             |
| 00000080  | End of curve                         |
| 00000100  | Broken belt                          |
| 00000200  | Not used                             |
| 00000400  | Not used                             |
| 00000800  | Reserved                             |
| 00001000  | Reserved                             |
| 00002000  | Reserved                             |
| 00004000  | Reserved                             |
| 00008000  | Reserved                             |
| 00010000  | Reserved                             |
| 00020000  | Not used                             |
| 00040000  | Fans error                           |
| 00080000  | ECB error                            |
| 00100000  | Reserved                             |
| 00200000  | Reserved                             |
| 00400000  | Reserved                             |
| 00800000  | Reserved                             |
| 01000000  | Reserved                             |
| 02000000  | Reserved                             |
| 04000000  | Reserved                             |
| 08000000  | Reserved                             |
| 10000000  | Reserved                             |
| 20000000  | Reserved                             |
| 40000000  | Reserved                             |
| 80000000  | Reserved                             |

### 8.3 Warning words

#### Warning words, 16-92

| Bit (Hex) | Warning words                     |
|-----------|-----------------------------------|
| 00000001  | Brake check                       |
| 00000002  | Power card over temperature       |
| 00000004  | Earth fault                       |
| 00000008  | Control card over temperature     |
| 00000010  | Control word timeout              |
| 00000020  | Over current                      |
| 00000040  | Torque limit                      |
| 00000080  | Motor thermistor over temperature |
| 00000100  | Motor ETR over temperature        |
| 00000200  | Inverter overloaded               |

| Bit (Hex) | Warning words                |
|-----------|------------------------------|
| 00000400  | DC link under voltage        |
| 00000800  | DC link over voltage         |
| 00001000  | DC link voltage low          |
| 00002000  | DC link voltage high         |
| 00004000  | Mains phase loss             |
| 00008000  | No motor                     |
| 00010000  | Live zero error              |
| 00020000  | 10 V low                     |
| 00040000  | Brake resistor power limit   |
| 00080000  | Brake resistor short circuit |
| 00100000  | Brake chopper fault          |
| 00200000  | Speed limit                  |
| 00400000  | Fieldbus communication fault |
| 00800000  | 24 V supply fault            |
| 01000000  | Mains failure                |
| 02000000  | Current limit                |
| 04000000  | Low temperature              |
| 08000000  | Voltage limit                |
| 10000000  | Encoder loss                 |
| 20000000  | Output frequency limit       |
| 40000000  | Not used                     |
| 80000000  | Not used                     |

#### Warning words, 16-93

| Bit (Hex) | Warning words |
|-----------|---------------|
| 00000001  | Start delayed |
| 00000002  | Stop delayed  |
| 00000004  | Clock failure |
| 00000008  | Reserved      |
| 00000010  | Reserved      |
| 00000020  | No flow       |
| 00000040  | Dry pump      |
| 00000080  | End of curve  |
| 00000100  | Broken belt   |
| 00000200  | Not used      |
| 00000400  | Reserved      |
| 00000800  | Reserved      |
| 00001000  | Reserved      |
| 00002000  | Reserved      |
| 00004000  | Reserved      |
| 00008000  | Reserved      |
| 00010000  | Reserved      |
| 00020000  | Not used      |
| 00040000  | Fans warning  |
| 00080000  | ECB warning   |
| 00100000  | Reserved      |
| 00200000  | Reserved      |
| 00400000  | Reserved      |
| 00800000  | Reserved      |
| 01000000  | Reserved      |
| 02000000  | Reserved      |
| 04000000  | Reserved      |
| 08000000  | Reserved      |
| 10000000  | Reserved      |
| 20000000  | Reserved      |
| 40000000  | Reserved      |
| 80000000  | Reserved      |

|                         |
|-------------------------|
| <b>93400872 04.2025</b> |
| ECM: 1420859            |